



# How to patch a dry wall hole.

This fast and easy guide will help you patch a dry wall hole.

Written By: Ashesh Patel



## INTRODUCTION

This guide will help you patch a dry wall hole using drywall joint compound, paint scraper and a cleaning tool (I'll be using wet kitchen tissue).

---



### TOOLS:

- [Soft Cloth](#) (1)
- [Paint Scraper](#) (1)
- [Drywall Joint Compound](#) (1)

*This can be found at any local hardware store.*

---

## Step 1 — How to patch a dry wall hole.



- Clean up the area you want to patch with a wet soft cloth. Pat it dry.

## Step 2



- Mix the compound. Make sure to avoid chunks.
- Apply the compound.
- Spread it out to an even and smooth surface.
- Allow it to dry over night.
- If needed, use a sandpaper to even out the surface.
- Note: This step should be repeated until you achieve smooth and even surface.

## Step 3



- Repeat step two until you have the desired result. It should look smooth and even.
- Note: Dry wall compound is typically white. Paint might be needed if the drywall compound doesn't match with the door's finish.

---

Paint can be used after the compound has dried off to match your door's finish. There are guides available online to help you paint over the drywall compound.

This document was last generated on 2017-06-18 10:01:56 AM.